

## Instructions for change the chip in:

HP 3000 / 3600 / 3800 / 4700 / 4730

### Step 1 | Remove the original chip from laser cartridge



### Step 2 | Insert the new chip nin laser cartridge has it's represented in the following pictures



For further information please contact our commercial department:  
Tel. 00351 21 232 84 00 / 26 \* Fax. 00351 21 232 84 90 \* Email. [info@iberlaser.net](mailto:info@iberlaser.net)