

Instructions for change the chip in:

HP 2600 / 2605 / 1600

Step 1 | Remove the original chip from laser cartridge



Step 2 | Insert the new chip nin laser cartridge has it's represented in the following pictures



For further information please contact our commercial department:
Tel. 00351 21 232 84 00 / 26 * Fax. 00351 21 232 84 90 * Email. info@iberlaser.net